


Accessory List

BVM Volume Measurement



Rigs and Probes for Optimal Volume Measurement



Official Method:
AACCI 10-14.01

Perten
INSTRUMENTS
a PerkinElmer company

Accessories BVM

Introduction

To get the best results when using the BVM, the product has to be in a stable position. This is done by choosing the correct attachment for the product.

The below points should be considered when choosing a suitable attachment:

- * It shall give sufficient support to hold the product in the same position. It is important that the product does not fall from the support or change position during rotation/analysis.
- * It shall be as small as possible to minimize the non-product volume that the laser measures and to avoid deformation of the product while attaching it. The attachment height and volume is corrected for in the software if correct attachment is selected in the software method.
- * It shall be tightly attached to the product.

This brochure contains the standard attachments available for the BVM. For further information, please contact Perten Instruments.

Hook attachments



Hook attachment 2 needles 8 mm apart

HA2P8

Part # 661281

Hook attachment 2 points 17 mm apart

HA2P17

Part # 661217

Hook attachment 2 points 33 mm apart

HA2P33

Part # 661233

Hook attachment 2 points 50 mm apart

HA2P50

Part # 661250

Hook attachment 4 points

HA4P

Part # 661400

Flat supports - Rectangular



Flat support plate, rectangular, 15x20 mm	FSPR1520	Part # 664011
Flat support plate, rectangular, 15x40 mm	FSPR1540	Part # 664021
Flat support plate, rectangular, 30x50 mm	FSPR3050	Part # 664031
Flat support plate, rectangular, 30x80 mm	FSPR3080	Part # 664041
Flat support plate, rectangular, 50x70 mm	FSPR5070	Part # 664051
Flat support plate, rectangular, 60x130 mm	FSPR60130	Part # 664061
Flat support plate, rectangular, 70x80 mm	FSPR7080	Part # 664071
Flat support plate, rectangular, Custom made	FSPRCM	Part # 664099

Flat supports - Circular



Flat support plate, circular, d=30 mm	FSPC30	Part # 663003
Flat support plate, circular, d=50 mm	FSPC50	Part # 663005
Flat support plate, circular, d=100 mm	FSPC100	Part # 663010
Flat support plate, circular, d=140 mm	FSPC140	Part # 663014
Flat support plate, circular, d=160 mm	FSPC160	Part # 663016
Flat support plate, circular, d=200 mm	FSPC200	Part # 663020
Flat support plate, circular, d=250 mm	FSPC250	Part # 663025
Flat support plate, circular, Custom made	FSPCCM	Part # 663099

Adjustable attachments



Adjustable attachment, 1 needle 10 mm long	BA-A1N-10	Part # 661011
Adjustable attachment, 1 needle 30 mm long, 5 mm stop	BA-A1N-30-5	Part # 661013
Adjustable attachment, 2 needles 8 mm long	BA-A2N-8	Part # 661028
Adjustable adapter, d=6mm	BA-AA6	Part # 661006

Spare parts

Support shafts

Support shaft, 325 mm, for BVM 6600	Part # 660506
Support shaft, 200 mm, for BVM 6610, (from S/N 2143252)	Part # 660135
Support shaft, 250 mm, for BVM 6630/6640, (from S/N 2143252)	Part # 660136
Support shaft, 370 mm, for BVM 6630/6640, (from S/N 2143252)	Part # 660137

Calibration Weight



BVM calibration weight platform	Part # 660121
Calibration Weight, 1 Kg, with plastic cover	Part # 679001
99 mm Calibration Cylinder for BVM	Part # 660092
For BVM 6600 and older models with cylinder based calibration.	

PERTEN INSTRUMENTS AB

P.O. Box 9006

126 09 Hägersten, Sweden

customerservice@perthen.com

Tel: +46 8 505 80 900

Fax: +46 8 505 80 990

2017-11-22